Manual Stretcher - ToronCare™ 1170



Features and Applications:

- Manual type transfer stretcher.
- Single crank is used for height adjustment, stretcher can be positioned up and down by turning the crank clockwise and anti-clockwise respectively.
- Bright arrow symbols direct the user how to operate clearly.
- Central locking castors are matched with direction castor under the chassis, which helps the user for easy control of stretcher direction
- Patient on the mattress can be moved parallel to another bed or flat table by rotating the upper crank handle.
- Rotary rollover protective railing
- Insulating bed board



Technical Specifications:

Dimensions	
Overall dimensions (LxW)	1955x635mm (76.9x25.0 in)
Height adjustment (Bed board to ground)	850-590mm (33.5-23.2 in)
Size of mattress (LxW)	1880x555mm (74.0x21.8 in)
Diameter of Central-lock castor	150mm (5.9 in)
Horizontal move range	400mm (15.7 in)
Weight	
Net Weight	92 Kg (203 lbs)









Standard Accessories (Included):

• I.V Pole





559-24-0