



CATALOGUE

2014

TTABO-Gravel Pump



PRODUCT BROCHURE

**TORONTECH™
PUMPS**

TORONTECH.COM



Torontech™ is a leading North American based international manufacturer and supplier of pumps, pipes, valves & actuators. The Torontech™ group has established an extensive network in the USA as well as international markets and remains to be a preferred vendor of choice supplying quality pumps for today's leading corporations.

Creating comprehensive solutions for our clients has always been the core value of our company. From sales, to order execution, and post-sales support; every staff member is here to assist you in selecting the solution that best suits your unique requirements and budget.

The Torontech™ group offers a complete range of quality pumps that are, ANSI to ISO approved and engineered to last, ensuring your company continuous production without interruptions.

Since the beginning, we have succeeded in only offering quality manufactured pumps that are currently being used worldwide. We offer the best value for your investment and provide world-class support.

Due to the demand for our quality pumps, Torontech™ has experience explosive growth primarily in the oil & gas, water filtration and chemical refinery industries.

We offer an extensive range of solutions and products for oil & gas projects, refineries, petrochemical plants, and marine applications. Our main class of pumps includes API (American Petroleum Institute) Standard, Mining, Water & Sewage and Firefighting applications. The pumps are offered in various configurations depending on orientation of the pump, required head and type of fuel used for operation.

TTABO-Gravel Pump

Features of product

D: 100-400mm
Q:36-5040 m3/h
H: 5-80m



Specifications:

- high-head gravel pump,abrasion resistance material
- application for river dredging sand pump.
- high pressure mud pump

Function Introduction:

- horizontal cantilevered single-casing centrifugal gravel pump.
- pump discharge direction in any of 360. easy installation.
- cylinder bearing assembly,oil lubrication ,adjusting the distance between impeller and pump,
- mechanical seal, expeller seal and packing seal
- wide passage , good performance of NPSH, anti-wearing and anti-corrosion, high efficiency
- v belt driver, gearbox driver, elastic coupling driver, fluid couplings driver, frequency conversion driver, silicon controlled rectifier speed regulation etc.



Torontech™ – North America
TEL:+1 (416) 368-2721
FAX:+1 (416) 981-7652
E-MAIL: sales@Torontech.com
WEB:www.Torontech.com

Please contact us for your nearest local office or distributor